

DEGREASER 260

DEGREASER:

- Degreases new and used mesh
- Non-abrasive - does not induce premature mesh breakdown
- Removes residual hand oils and printing inks
- Freeze/Thaw Stable

INK DEGRADER:

- Emulsifies inks for easy water removal before reclaiming
- Safe, water-based formula
- Non-flammable
- Pleasant fragrance
- Cleans squeegees, flood bars, frames, etc.
- Degrades plastisol, UV, solvent-based and water based inks

INSTRUCTIONS:

Ink Degrading: Remove excess ink from screen. Apply an amount of Degreaser 260 to cover residual ink. Using dedicated nylon scrub pad or brush, agitate in a circular motion on both sides of the screen. Ink will immediately emulsify. Rinse with water.

Degreasing: After removing stencil with image mate Reclaimer 660, apply Degreaser 260 to wet screen. Degreaser 260 will cling to the screen. Using a clean nylon scrub pad or brush, spread Degreaser 260 with light agitation in a circular motion. Work up lather on both sides of the screen. Degreaser 260 may be left on screen to dwell while wet. Rinse with a garden hose.

Dehazing: Apply Degreaser 260 to open image areas. Scrub with dedicated nylon scrub pad or brush. If area has been stained for an extended time, allow Degreaser 260 to penetrate for 2 to 5 minutes. Follow up with scrubbing; rinse with water. Pressure wash if necessary.



DEHAZER:

- Prevents ink haze
- Safe, non-caustic formula
- Won't burn skin and clothing
- Does not deteriorate mesh like caustic products
- Removes old images from polyester and stainless steel mesh

STANDARD SIZES

- 1 quart, 1 gallon, 5 gallon, 55 gal. drum

For Technical Service
Call Toll Free **1-800-328-4261**
(Outside North America Call +1-218-628-2217)
Email: help@chromaline.com



Chromaline Screen Print Products

4832 Grand Ave. • Duluth, Minnesota 55807 • Tel: 218.628.2217
Fax: 218.628.3245 • Web Site: www.chromaline.com
E-mail: sales@chromaline.com